

Wi-Fi Audio Video Transmitter

Manual



Contents

1. Introduction-----	2
2. Way of Connection -----	2
3. User Manual-----	3
4. Specifications -----	4
5. Operation Steps-----	4
6. Application in Tablet Personal Com-----	4
7. Application in Apple Series and Laptop-----	7
8. Downloading Software for Tablet and Laptop-----	9
9. Trouble Shooting-----	9


1. Introduction

This new product has applied the most popular Wi-Fi technology in transmitting the video signals from the camera head and audio signals from MIC after being code processed to the tablet personal computer or mobile phone to display the monitoring pictures and play the voice (the voice is sent from MIC of transmitter to tablet or mobile phone). The transmitter has adopted built-in rechargeable Li-ion battery.

2. Connection



3. User Manual



- | | | | |
|---------------|--------------|------------|--------|
| 1. CAM | 2. Power LED | 3. LED ADJ | 4. MIC |
| 5. Charge led | 6. Ready | 7. Charge | 8. ANT |

NOTE: Turn on the transmitter by switching 3 clockwise. Turn off the transmitter by switching 3 counterclockwise.

4. Specifications

Transmitting Distance in open area :100 meters (328FT)

Working Time:> 2 hours

Handheld Receiver Operating System:IOS, ANDROID and Windows (Windows is not recommended)

5. Operation Steps

Step 1: Screw the antenna on the transmitter

Step 2: Connect the transmitter and the cable reel with the soft cable

Step 3: Turn on the transmitter by switching clockwise. LED lights of Camera head will be on.

Step 4: Download the software. Then make the settings when the transmitter is turned ON. Please refer to the application in Tablet, Apple Series and Laptop as follows for details.

6. Application in Tablet Personal Computer

- 1) Install ELCam_Android_20120824-2.apk software on Tablet Personal Computer that

supports Android and  icon will be displayed after successful installation.

- 2) Click the “settings and Wireless & networks” on the tablet and then click “FORBESTXXX” or “VideoHome” in the list of Wi-Fi settings. Password is “12345678”. “Connected to

FORBESTXXX” or “Connected to VideoHome” will be displayed in the Wi-Fi settings.

- 3) Click M-iCAM icon on the tablet and enter the monitoring pictures



4) Function Keys



Setting:

- a) Wi-Fi Setting
- b) Video Setting : Select MPEG4 VGA
- c) Reset to Default : Manufacturer setting
- d) About: Software version



SEND MUSIC: Not applicable in Android



Video: Turn on/off videos



AUDIO: Turn on/off audio from MIC



Talk: Turn on/off the voice transmitting from Tablet to Wi-Fi transmitter. This function is not applicable for this device



Not Applicable in Android



SNAP SHOT: Take pictures and pictures will be saved in the folder



Video Recording



PLAY VIDEO: Play the recorded video



Speaker Volume



MIC Volume

7. Application in Apple Series and Laptop

5) For the **Apple series** that support IOS, please download M-icam from app download. User manual for IOS is the same as that for **Android**.

6) Minimum Requirement for Android Tablet

Personal Computer: android3.0

For Android Mobile Phone, android2.0.3 is OK

- 7) For **laptop** with Wi-Fi that supports windows, please install the software setup.exe. Select “FORBESTxxx” in the list of wireless setting and password is “12345678”.

Then click the icon  on the boot interface.

Following picture will be displayed:





And then click the icon  , monitoring picture transmitted from the camera head will be displayed.

8. Downloading Software for Tablet and Laptop

Please download the software [ELCam](#)
[Android_20120824-2.apk](#) for Tablet and [Windows](#)
[setup](#) for Laptop from www.gdalltop.com

9. Trouble Shooting

Blurring Pictures: Maybe not enough voltage so please recharge the battery Work less than 2 hours after fully recharged: Battery breakdown so please change the battery

Not receiving Wi-Fi signals: The signal light of Ready is still red and please wait for the light to turn green. Make sure that you make the settings when the transmitter is turned on. If the light remains in red, there might be a problem of incompatibility between the transmitter and your display. Please try with other one.